InClimate

PROGRAMMING TOOL

Fast and easy interface module for
programming of InClimate via Laptop with serial USB port
inclusive user-friendly software for programming and change
of ModBus address and register

senmatic

InClimate

PROGRAMMING TOOL



The InClimate programming tool is a Windows-based plug-in tool, which makes the set-up of InClimate easy - for everyone - experienced or beginners.
An all-in-one tool, which saves time and trouble when setting up the InClimate sensor.
The softwaren is free of charge and can be downloaded from **www.senmatic.dk/sensorer/InClimate**.

Ordering number: **307-009**
InClimate programming tool, incl. software.
Supplied with USB-plug, cable, and programming unit.





A log can be stored as documentation for the programmed settings of InClimates

Senmatic A/S - Industrivej 8 - DK-5471 Søndersø - DENMARK
Tel.: +45 64892211 - Fax: +45 64893311 - dk@senmatic.com - www.senmatic.com